5. Block Diagram

5-1 Main



CD PART


CD DISC
PD.A.B.C.D.E.F
LD.VC
L
G
R
UIC1
KS57C2316
MICOM
WIC1
KB9223
ASP
DECK ASSY
CMS-P30AM6UD
OPTICAL PART
ACTUATOR PART
RF PART
SERVO
PART
AUDIO
FILTER
FOK.ISTAT
XRST.MDAT.MCK
MLT.MUTE
MICOM
PART
TEO
FEO
SPO
SLO
TRACK
FOCUS
SPINDLE
SLED
SMEF
SMON
LOCK
SMSD
SMDP
EFM
TRCNT
ISTAT.SOS1.SQDT
SQCK.XRST.MDAT.MCK.MLT
AUDIO
L/R
WIC71
KA9258
IC-DRIVER
MOTOR/ACTUATOR
DRIVER PART
VCC POWER PART
VCC +5V
DSP
PART
BUFFER
DAC
PART
8 OVER
WIC51
KS9286
DSP
DIGITAL
OUTPUT
+8V
+5V
MAIN B+[+8V]